



During the initial set up, you will name your fireplace. In the examples below the name "FIREPLACE" was chosen. Keep this reference card handy while learning how to control your fireplace through voice commands.

**IT IS IMPORTANT TO USE THE EXACT PHRASES AS VARIATIONS MAY NOT WORK.**

HEY ALEXA TURN ON FIREPLACE

- Turns on Fireplace to the last settings for flame and ember lights, with no heat. If the last command was "OFF" the default lights with no heat will activate.

HEY ALEXA TURN OFF FIREPLACE

- Turns the Fireplace fully off.

HEY ALEXA FIREPLACE HEAT ON or SET FIREPLACE HEAT TO ON

- Turns ON the Fireplace, with HEATTERS set to HIGH setting (2 Heaters active, temperature set to level 5 (25°C/77°F))

HEY ALEXA FIREPLACE HEAT TO LOW or SET FIREPLACE HEAT TO LOW

- Turns on the fireplace with HEATTERS set to low setting; (1 Heater active, temperature set to level 5 (25°C/77°F))

HEY ALEXA FIREPLACE HEAT TO HIGH or SET FIREPLACE HEAT TO HIGH

- Turns ON the Fireplace, with HEATTERS set to HIGH setting (2 Heaters active, temperature set to level 5 (25°C/77°F))

HEY ALEXA FIREPLACE HEAT OFF or SET FIREPLACE HEAT TO OFF

- Turns Fireplace heat off.

HEY GOOGLE TURN ON FIREPLACE or FIREPLACE ON

- Turns on Fireplace to the last settings for flame and ember lights, with no HEAT. If the last active setting was "OFF", then default lights with no heat will activate

HEY GOOGLE TURN OFF FIREPLACE or FIREPLACE OFF or SET FIREPLACE TO OFF

- Turns the Fireplace fully off.

HEY GOOGLE TURN FIREPLACE HEAT ON or FIREPLACE HEAT ON or SET FIREPLACE HEATTERS TO ON

- Turns ON the Fireplace, with HEAT set to HIGH setting (2 Heaters active, temperature set to level 5 (25°C/77°F))

HEY GOOGLE TURN FIREPLACE HEAT TO LOW or FIREPLACE HEAT TO LOW or SET FIREPLACE HEAT TO LOW

- Turns on the fireplace with HEATTER set to low setting; (1 Heater active, temperature set to level 5 (25°C/77°F))

HEY GOOGLE TURN FIREPLACE HEAT TO HIGH or FIREPLACE HEAT TO HIGH or SET FIREPLACE HEAT TO HIGH

- Turns ON the Fireplace, with HEATTERS set to HIGH setting (2 Heaters active, temperature set to level 5 (25°C/77°F))

HEY GOOGLE TURN FIREPLACE HEAT OFF or FIREPLACE HEAT OFF or SET FIREPLACE HEAT TO OFF

- Turns Fireplace heat off fully



During the initial set up, you will name your fireplace. In the examples below the name "FIREPLACE" was chosen. Keep this reference card handy while learning how to control your fireplace through voice commands.

**IT IS IMPORTANT TO USE THE EXACT PHRASES AS VARIATIONS MAY NOT WORK.**

HEY ALEXA TURN ON FIREPLACE

- Turns on Fireplace to the last settings for flame and ember lights, with no heat. If the last command was "OFF" the default lights with no heat will activate.

HEY ALEXA TURN OFF FIREPLACE

- Turns the Fireplace fully off.

HEY ALEXA FIREPLACE HEAT ON or SET FIREPLACE HEAT TO ON

- Turns ON the Fireplace, with HEATTERS set to HIGH setting (2 Heaters active, temperature set to level 5 (25°C/77°F))

HEY ALEXA FIREPLACE HEAT TO LOW or SET FIREPLACE HEAT TO LOW

- Turns on the fireplace with HEATTERS set to low setting; (1 Heater active, temperature set to level 5 (25°C/77°F))

HEY ALEXA FIREPLACE HEAT TO HIGH or SET FIREPLACE HEAT TO HIGH

- Turns ON the Fireplace, with HEATTERS set to HIGH setting (2 Heaters active, temperature set to level 5 (25°C/77°F))

HEY ALEXA FIREPLACE HEAT OFF or SET FIREPLACE HEAT TO OFF

- Turns Fireplace heat off.

HEY GOOGLE TURN ON FIREPLACE or FIREPLACE ON

- Turns on Fireplace to the last settings for flame and ember lights, with no HEAT. If the last active setting was "OFF", then default lights with no heat will activate

HEY GOOGLE TURN OFF FIREPLACE or FIREPLACE OFF or SET FIREPLACE TO OFF

- Turns the Fireplace fully off.

HEY GOOGLE TURN FIREPLACE HEAT ON or FIREPLACE HEAT ON or SET FIREPLACE HEATTERS TO ON

- Turns ON the Fireplace, with HEAT set to HIGH setting (2 Heaters active, temperature set to level 5 (25°C/77°F))

HEY GOOGLE TURN FIREPLACE HEAT TO LOW or FIREPLACE HEAT TO LOW or SET FIREPLACE HEAT TO LOW

- Turns on the fireplace with HEATTER set to low setting; (1 Heater active, temperature set to level 5 (25°C/77°F))

HEY GOOGLE TURN FIREPLACE HEAT TO HIGH or FIREPLACE HEAT TO HIGH or SET FIREPLACE HEAT TO HIGH

- Turns ON the Fireplace, with HEATTERS set to HIGH setting (2 Heaters active, temperature set to level 5 (25°C/77°F))

HEY GOOGLE TURN FIREPLACE HEAT OFF or FIREPLACE HEAT OFF or SET FIREPLACE HEAT TO OFF

- Turns Fireplace heat off fully